

## Installation for Windows 3.1 and 3.11

First start Windows on your PC. Now the SETUP.EXE program on the utility disk can be started. Please follow the instructions of the program.

### Using DCFWIN.EXE

First you have to set the COM port. Select the DCFWIN icon and select Files/Properties.

Description	: DCFWIN
Command line	: DCFWIN.EXE
Working dir	: C: \DCFWIN\

Now type the name of the COM port and the time interval after DCFWIN.EXE on the command line.

COM1 = /C1  
COM2 = /C2  
COM3 = /C3  
COM4 = /C4

Direct time setting = /S0  
Time interval (min.) = /Sx (x= 1 - 65000 minutes)

Example for COM1 and 1 hour time setting :

Description	: DCFWIN
Command line	: DCFWIN.EXE /C1 /S60
Working dir	: C: \DCFWIN\

After you start the program it will appear minimized on the windows desktop. If the program cannot communicate with the DCF clock, a cross will appear in the icon. If you click twice on the icon you can read the error message and selected COM and time values.

To run the program every time you start Windows you have to copy the Icon of DCFWIN.EXE to the STARTUP folder.